

AIRPORT	ICAO	CTAF	TWR	RWY	RWY DIST	ELEV
Boleráz - Trnava	LZTR	132,080		14/32 G	1200m	666ft
Bratislava - M.R. Štefánik	LZIB		118,300	04/22 C 13/31 C	2900m 2950m	436ft
Dubnica - Slávnica	LZDB	122,340		05/23 G	1100m	771ft
Dubová	LZDV	123,930		13/31 G	575m	634ft
Holíč	LZHL	123,680		04/22 G	1200m	528ft
Jasná - Gôtovany	LZJS	130,130		08/26 A	544m	2103ft
Kamenica nad Čirochou	LZKC	122,605		07/25 G	870m	571ft
Košice	LZKZ		120,400	01/19 C	3100m	755ft
Lučenec - Boľkovce	LZLU	123,060		13/31 A	800m	709ft
Malacky - Kuchyňa (Mil)	LZMC		129,575	01/19 C	2500m	689ft
Martin - Tomčany	LZMA	120,040		18/36 G	800m	1378ft
Nitra - Janíkovce	LZNI	123,405		15/33 G	1080m	443ft
Nové Zámky	LZNZ	120,055		16/34 G	1001m	376ft
Očová	LZOC	123,605	122,905	08/26 G	780m	1207ft
Partizánske - Malé Bielice	LZPT	123,935		07/25 G	920m	604ft
Piešťany	LZPP	118,575	118,575	01/19 C	2000m	545ft
Poprad - Tatry	LZTT	122,065	121,350	09/27 C 07/25 G	2600m 760m	2356ft
Prievidza	LZPE	123,055		04/22 A+G	949m	854ft
Prešov (Mil)	LZPW		135,500	05/23 G	800m	1053ft
Ružomberok	LZRU	123,030		06/24 G	940m	1614ft
Ražňany - Sabinov	LZRY	122,135	135,500	16/34 G	1050m	1053ft
Senica	LZSE	123,605		12/30 A+G	1080m	620ft
Sliač - Tri Duby (Mil & Civ)	LZSL		122,905	18/36 C	2400m	1044ft
Svidník	LZSK	123,405		01/19 A	1200m	1161ft
Spišská Nová Ves	LZSV	123,505		12/30 G	1362m	1624ft
Šurany	LZSY	132,785		15/33 G	640m	394ft
Trenčín	LZTN	132,015		04/22 C 03/21 G	2000m 1000m	676ft
Žilina	LZZI	123,685	118,400	06/24 C	1150m	1020ft

A - asphalt rwy, C - concrete rwy, G - grass rwy

STATION	FREQ	OPERATIONAL HOURS (!!!ALWAYS CHECK VALID NOTAMS!!!)
Bratislava INFORMATION	124,300	LZIB AD+ATS H24
Bratislava VOLMET	126,200	LZKZ AD+ATS H24
Štefánik RADAR	134,925	LZPP AD: MON – FRI: 07:15 – 19:00 (06:15 – 18:00) ATS: MON – FRI: 07:15 – 19:00 (06:15 – 18:00) Outside OPR HR + SAT, SUN, HOL - class G airspace.
Štefánik GROUND	120,905	LZZI AD: MON – FRI: 07:00 – 15:00 (06:00 – 14:00) ATS: MON – FRI: 07:00 – 15:00 (06:00 – 14:00) Outside OPR HR + SAT, SUN, HOL - class G airspace.
Malacky RADAR	120,750	LZSL AD: MON – FRI: 07:00 – 17:00 (06:00 – 16:00) ATS: MON – SUN: 06:30 – 18:30 (05:30 – 17:30) Outside OPR HR of Sliač TWR the Sliač CTR is declared as LZR225. Type of restriction, see AIP ENR 5.1.3.
Sliač RADAR	119,155	LZTT AD: MON-SUN: 0615-1800 (0515-1700) ATS: MON-SUN: 0615-1800 (0515-1700) Outside OPR HR - class G airspace.
Košice RADAR	129,350	
Handling Airport Bratislava	131,850	
Handling Košice	131,855	
Handling Poprad-Tatry	131,855	
ATIS Štefánik ARR	133,880	
ATIS Štefánik DEP	128,655	
ATIS Košice	133,730	
ATIS Poprad-Tatry	133,130	

CONTACT	NUMBER	FACILITY - ILS	IDENT	FREQ	FACILITY - VOR	IDENT	FREQ
CARO - FPL	+421 248 572 280	LZIB ILS RWY 22	OKR	108,300	Janovce VOR/DME	JAN	110,800
FIC - Bratislava INFO	+421 248 572 230	LZIB ILS RWY 31	OB	110,700	Nitra VOR/DME	NIT	116,500
AMC - military areas	+421 960 463 579	LZKZ ILS RWY 01	KE	109,500	Sliač VOR/DME	SLC	114,000
Handling LZIB	+421 233 033 354	LZPP ILS RWY 01	CN	109,300	Poprad VOR/DME	PPD	112,100
Ján Klačman - HT	+421 910 999 977	LZSL ILS RWY 36	FS	108,700	Košice VOR/DME	KSC	108,200
Richard Fritz - maintenance	+421 903 999 975	LZTT ILS RWY 27	TT	110,100			
Tomáš Fait - ground ops	+421 910 953 530	LZZI ILS RWY 06	ZNA	108,150			
Aircraft booking LZTN	+421 910 999 976						
SEAGLE Bratislava	+421 903 999 967						

ONLINE FLIGHT PLANNING

www.lps.sk/ibaf
Login: seagleairfto Password: ftsk02